



Productivity through Precision®

Schmitt Industries, Inc
8000 NE 14th Place
Portland, Oregon 97211 USA
Tel.: +1 503.210.5733
Fax: +1 503 223 1258
www.acuitylaser.com

Acuity® AR 2700 Part Number Guide

AR2700

AR2700 Ordering Information

Part#	Description
	AR2700 Laser Sensors
AP2700232	AR2700 Sensor: RS232/RS422, 4-20mA
	AR2700 Connectivity Kits
AQ7000001	Connectivity Kit – US Plug
AQ7000002	Connectivity Kit – EU Plug
AQ7000005	Connectivity Kit – US Plug (serial to USB)
AQ7000006	Connectivity Kit – EU Plug (serial to USB)
	AR2700 Miscellaneous Parts
AP2500007	Cable Assembly: AR2700 sensor unit 2m

*See page 2 for ordering descriptions, if needed.



Productivity through Precision®

Schmitt Industries, Inc
8000 NE 14th Place
Portland, Oregon 97211 USA
Tel.: +1 503.210.5733
Fax: +1 503 223 1258
www.acuitylaser.com

Acuity® AR 2700 Part Number Guide

Accessory Ordering Guide

Connectivity Kits: Acuity sells a connectivity kit to aid in connecting your laser to a power supply and serial port. This product includes a 120V, 15 VDC, AC power supply; a serial cable with DB9 connector; and a solid-state, NEMA-4X interface box. The interface box includes two sets of terminal blocks for simple input (from sensor) and output (to your selected device), a DB9 male serial connector out, and a barrel style power connector in. You can either pass through the wiring to another unterminated cable, connect a DB9 serial cable directly to the interface box, or both at the same time.

AQ7000001 - 120 V version with an US-style plug

AQ7000002 - 240 V version with a European-style plug

AQ7000005 – w/ serial to USB cable for ease of connection into industrial computers - US plug

AQ7000006 – w/ serial to USB cable for ease of connection into industrial computers - Euro plug

Cables: Longer cable lengths available upon request